



**USER MANUAL**

**Bridge Saw Machine GQ-3220B**



## Content

<b>Operating Instructions</b> .....	2
1. Instructions .....	4
1.1 Cut slab .....	4
1.2 45-degree chamfered cut usage .....	9
1.3 Table Up & Down .....	10
2. Equal thickness cut (Used for milling table) .....	13
3. Linkage cut .....	15
4. Quick linkage .....	18
5. Miter 45° .....	20
6. Auto Cut Hole (Under Developing).....	23
7. System Check .....	26
8. Parameter.....	27
Problems that the Bridge Saw Machine may encounter in practical cutting .....	30



## Operating Instructions

### [Pay attention]

1. Make sure that the motor and drive are properly installed, firmly fixed, and the power supply and voltage wiring are correct before powering on.
2. During debugging, the motor should be unloaded first, and after confirming that the parameters are correct, then carry out load debugging to prevent damage to the machine caused by incorrect operation.
3. Do not switch on and off the system frequently to prevent damage to the drive.
4. The drive and motor may heat up after running for a period of time. It is strictly forbidden to touch the drive radiator and motor during running and for a period of time after power off!
5. When an accident occurs or the motor does not operate normally, press the emergency stop button immediately, and the machine will immediately stop running!

### [Danger]


Even after the drive is powered off, the high voltage will remain for a period of time. Do not disassemble the power cord within three minutes after the power is turned off, don't touch the terminal block.

It is strictly forbidden to disassemble the driver and motor with power on.

The personnel involved in disassembly and maintenance must have corresponding professional knowledge and working ability.

### [Four Axis Bridge Saw operation precautions]

1. No matter what speed is required to cut the plate, you must first press the "Motor Start" button, wait until the main motor reaches the speed (hear the Motor sound stable), and then cut the plate, otherwise it may cause machine failure or damage to the saw blade!

2. If there is an error action on the machine, be sure to press , or restart the machine, do not disassemble the original parts at will.


3. When manually moving the position of the saw blade, try to maintain a certain time interval between the two operations, and do not operate too intensively, otherwise it may cause the PLC data transmission is not timely, and the driver out of tolerance alarm (ER 020) will occur. If the alarm occur, just power off and reboot the machine!
4. If the work is stopped due to a fault or power outage during the cutting process of the machine, the tool must be re-set after restarting the machine!
5. When the machine working table is flipped, the head must be at the right rear, otherwise it will hit the machine head!
6. When the machine arrives to install, the 4 overtravel-limit switch stoppers in Y direction should be installed on the outside.
7. Please don't forget to add hydraulic oil for the Bridge Cutter!
8. Before the machine is ready to cut, please check the state and various parameters of the Bridge Cutter to avoid unnecessary errors (e.g. damage to the saw blade), and then cut after confirming!
9. If the machine head does not return to position due to misoperation, enter the "System Settings" interface, open the "angle adjustment" function, and manually put the head back!

## 1. Instructions



(The screen displayed on the control panel when the machine is powered on)

### 1.1 Cut slab





When preparing for sheet cutting, select the function **Cut slab** of the control panel, the control interface is as shown above.

The text displayed in the red box represents the current state of the machine.



After entering the **Cut slab**:




**Saw offset: 00.0 MM**: Blade thickness compensation can be added here (first the original thickness of the blade is entered before cutting, if the cut out size is bigger, minus the extra size on the basis of the blade thickness; if the cut of size is smaller, plus the extra size on the basis of the blade thickness).



**1.1.1** When the function is shown as **Front cut** and the blade is in a state of 0 degree, the machine cuts forward (X).


When the blade is in a 90-degree state, the machine cuts to the right (Y).



**1.1.2** When the function is shown as **Behind cut** and the blade is in a state of 0 degree, the machine cuts backward (x).

When the blade is in a 90-degree state, the machine cuts to the left (Y).


(The blade is close to your direction for the forward cut direction, away from your direction for the backward cut direction)



**1.1.3** When the function is shown as **Low speed**, the X and Y axis of the machine is




running the **slow speed** value set in **Parameter**, as shown in the following image below.




1.1.4 The function is shown as  , the X and Y axis of the machine is running






the **slow speed** value set in  , as shown in the following image below.





**1.1.5** The interface of the , the higher the input speed of the x-axis and the y-axis when cutting the sheet, the higher the value entered, the faster the feed speed, adjust according to the hardness and thickness of the board. (The maximum limit is 40)



**1.1.6** Interface of the , is the current state of the head, when  change to , this indicates that the head is currently in its current state.




**1.1.7** When function is shown as  As shown in the following image:






In the state of continuous cutting, the machine only cuts the size displayed in the pink area. If the quantity of cut pieces is 0, the system will skip this group automatically.



### 1.1.8 When the function is shown as



In the state of a single-group cutting, the machine only cuts the size displayed in the green area of the first row.

When single group cutting is needed, you can set the required data in the box of each group first, and then click on which group you need.

For example, we need the data of the second group, click, and the second group of data will be displayed in the red box in the first row, at this time, single group cutting will only cut the data of the second group.


Note: Slabs cannot be stacked.

## 1.2 45-degree chamfered cut usage

Raise the machine head to the highest position, turn the 0°- 45° switch on the side of the control panel to the 45° direction, then the head of bridge cutter will go to 45°.

Setting blade: click “Start”, enter “Cut Slab”----- “Table Up & Down” ----- “Down”, and then drop the head down to the position where it can cut the working table.



If you only need to cut one knife: “”----- “single group cut”, the cutting length will be set a little longer, the naked eye to see the saw blade cut through slab, just press stop manually.

Attention: The 45° chamfering tool set should be distinguished from the straight-cut tool set.

### 1.3 Table Up & Down

The screenshot shows the main control interface with the following elements:

- Slab size Cut length Cut QTY** header at the top.
- Saw offset:** 00.0 MM (value in a red box).
- Groups table:**

Groups	Slab size	Cut length	Cut QTY
Group1	00000	00000	00
Group2	00000	00000	00
Group3	00000	00000	00
Group4	00000	00000	00
Group5	00000	00000	00
Group6	00000	00000	00
- Control buttons on the right:** Continue cut, Front cut, **Table up & down** (highlighted in red), Low speed, Back.
- Feed and Limit settings:** X Feed: 000.00, Y Feed: 000.00, Head upper limit, Head lower limit, Horizon Auto-cut, Vertical Auto-cut.

When preparing to lift the working table, select “

This block shows two buttons: a blue 'Cut slab' button and a green 'Table up & down' button.

The screenshot shows the dedicated control screen for the table movement with the following elements:

- Table up** (green button), **Stop** (yellow button), **Table down** (green button) buttons at the top.
- Table up time:** 000.0 (value in a green box).
- Table down time:** 000.0 (value in a green box).
- Main motor Speed:** Fast, Medium, Low buttons.
- Manual tool setting:** Down, Reset up & down limit buttons.
- Text:** Please close after tool setting completed.
- Back** button at the bottom right.



1.3.1 In the interface "Table Up & Down",


means three options of main motor speed, according to the thickness and hardness of different slabs, select different speeds (this function is only applicable to the machines with inverters; slow speed is 3000 rpm, medium speed is 3600 rpm, fast is 4500 rpm).



1.3.2 In the interface "Table Up & Down",



is mainly used for tool setting before cutting. Firstly, click




downward, then slowly click on the "Z-" lever several times, lower the saw blade





to the position just cut to the table, and the blade setting is completed, close

Raise the head, the lifting distance is determined by





: This parameter is used to compensate for the wear of the saw blade. It is cleared before setting the parameters. Assuming that the depth of the cutting board is set to 1MM and the rising height of the Z axis is set to 20MM, the cutting depth of the Z axis is 21MM at this time. The depth of the lower cutting board is set to a few millimeters, and the depth of the Z-axis lower knife will drop a few millimeters from the original foundation. Therefore, when setting the parameters, make sure that there is no problem before cutting to prevent damage

to the saw blade!


1.3.3 In the interface “Table Up & Down”,  means: If the machine has an error action, click  then the lower limit of the Z-axis will be reset to zero, and the machine will be ready to normal operation.


The use of “” :


the platform to be raised, click 


the platform to be lowered, click 


## 2. Equal thickness cut (Used for milling table)





Select  from the main function interface, as shown in the above picture.





2.1  means: At least ensure that the degree of coincidence is about 20%. For example: The thickness of the saw blade is 25mm, enter 20, and there will be a coincidence of 5mm for each cutting.

2.2  The entered value indicates how many tools are milled in total. (Divide the width of the table by the thickness of the slice to get an approximate value)


2.3  The entered value indicates the length for each milling tool.

2.4  The entered value indicates the speed for milling.

2.5 When function shown as , and the blade on 0 degree, the machine will cut forward; when the blade on 90 degree, the machine will cut backward.


2.6 When function shown as , and the blade on 0 degree, the machine will cut backward; when the blade on 90 degree, the machine will cut left.


**Instruction:** After the tool setting is completed, move to the starting point. After input all data,


click , the machine start milling table.

After milling completed, click , machine stop.

### 3. Linkage cut



Select , as shown in the above picture.








3.1 The interface of setting interface.

means: X-axis cutting parameter



those three group data means:



means: X axis cutting speed.



3.2 Linkage cut interface, the interface of cutting parameter setting interface.

means: Y axis



those three group data


means:




means: Y axis cutting speed.





means: After slab is placed on the table, the distance between the saw blade and the edge of the board to be offset in X direction.





means: After slab is placed on the table, the distance between the saw blade and the edge of the board to be offset in Y direction.




After input the size in the box, click  The X beam will automatically go to the specified position.



input the size in the box, click  , The X beam will move back the specified distance, click  ,The beam will move forward the specified distance (The maximum value can be set to 200)



: Mainly used for tool setting before cutting; lower the saw blade to a position close to

the table before cutting the slab, and then click  , now the Z axis can only move downward. It is the same as the drop selection function in the platform lifting interface. Same as

the function of  in the interface of  , so there is no need to switch the interface repeatedly.


Low speed

Same function like the **low speed** in **Cut slab**, Put this function here for easy operation, no need to switch the interface repeatedly.


Linkage cut

**Instructions:** After input all the cutting data of X axis and Y axis,


Linkage cut



click , The machine starts work automatically. After the cutting is completed, the head automatically raise.

#### 4. Quick linkage




Quick linkage

Select  from the main interface, as shown in the above picture.



4.1 The current X-axis and Y-axis current positions are displayed in the box, which is for reference to



4.2 Input size in box, and then click **Y Backward**, The X beam will automatically go to the specified position.




4.3

Input size in box, and then click




, The X beam will

move back the specified distance, click , The X beam will move forward the specified distance, the maximum distance is 200.


## 5. Miter 45°




Select from the main interface, as shown in the above picture.




5.1



means the width of forward cutting and reverse cutting can be cut, as shown in the figure below.



5.2





means: The length of the straight side of the slab, the input size can input little larger, to avoid can't cut through the slab.




**Instruction:**

Input all datas required for cutting, confirm that the machine head is at 0° position and click





If need forward 45° cut, click . If need reverse 45° cutting and when the head at





45°position, you have to return the head to 0° first, click  to make head back to 0° position.





After the head back to 0°, click , after cutting completed, click , and



then click  to closed this function.



All operations must be in  shown , If you directly turn the blade to 45° without first clicking 45° cut, then the blade will not be able to turn to 90°, at this moment, you must first click 45° cut, when it shows Start, then back the blade to 45° position.


**[Pay attention]**

If the machine accidentally turns off the 45° cut when the blade is in the 45° position, the blade cannot be automatically returned to 0° position at this time, and the blade can only be manually return in the system setting interface.


## 6. Auto Cut Hole (Under Developing)





Select **Auto cut hole** in the main interface, as shown in the above picture.








**6.1** In the interface “Auto cut hole”, of the “X cut” means X axis cutting length A, as shown in the picture below:




**6.2** In the interface “Auto cut hole”, of the “X cut” means the X Displacement distance from A1 to C1, as shown in the picture below:





**6.3** In the interface “Auto cut hole”, of the “X cut” means Cutting hole Length C, as shown in the picture below:







**6.4** In the interface “Auto cut hole”, of the “Y cut” means Y axis cutting length A1, as shown in the picture below:



**6.5** In the interface “Auto cut hole”, of the “Y cut” means the Y Displacement distance from A to C, as shown in the picture below:



**6.6** In the interface “Auto cut hole”, of the “Y cut” means Cutting hole Length C1, as shown in the picture below:







The use of **Auto cut hole**: after entering all the data required for Auto Cut Hole, click



**Hole cut**. Stop after the board is cut.

## 7. System Check



Select **System check** in the main interface, as shown in the above picture.

X0 Start	X15 Hydraulic alarm	Y0 Y output	Y13 Table down valve
X2 Auto-start	X16 0 degree sensor	Y1 X output	Y14 Z brake
X3 Home	X17 Driver alarm	Y2 Z output	Y15 Auto-oil
X4 Gantry Forward	X20 Front limit	Y3 A output	Y16 Auto-water cooling
X5 Gantry backward	X21 Back limit	Y4 Y inverse	45° 45° switch
X6 Saw left	X22 Left limit	Y5 X inverse	A Head CCW position
X7 Saw right	X23 Right limit	Y6 Z inverse	B Head CW position
X10 Saw up	X24 Z zero	Y7 A inverse	C Head memory position
X11 Saw down	M517 Rise limit	Y10 Blade motor KM	
X12 Head CCW	M518 Down limit	Y11 Hydraulic KM	
X13 Head CW	X26 Main motor alarm	Y12 Table rise valve	
X14 Stop	X27 External EMG		

[Back](#)

System check is mainly used to check the status of the machine. If the machine is faulty, you can check the machine based on the feedback of the system.

## 8. Parameter

### GANGERCNC Bridge Saw Cutting Machine

Cut slab

Equal THK cut

Linkage cut

Quick linkage

Auto cut hole

Miter 45°

System check


Parameter

ADD: Changqing District, Jinan city, Shangdong province.  
 TEL: 18906416766

FF : FF : FF    FFFF - FF - FF



Select **Parameter** in the main interface, as shown in the above picture.



8.1 In the interface “Parameter”,  means the

moving speed of the machine at , please refer to the instruction of




on page 4 for the details.

8.2 In the interface “Parameter”,  means the

speed of X axis and Y axis of Bridge Cutter at , please refer to the instruction of



on page 5 for the details.




**8.3** In the interface “Parameter”, means to compensate the offset of the saw blade wear, clear it to zero before tool setting each time. When the number in this box increases by 1mm, the cutting depth will increase by 1mm from the current depth.



**8.4** In the interface “Parameter”, means: when the machine




is closed, the distance of the machine head rising and falling each time.



**8.5** In the interface “Parameter”, means after the slab is placed on the table, the distance between the saw blade and the edge of the board to be offset in X direction.



**8.6** In the interface “Parameter”, means after the slab is placed on the table, the distance between the saw blade and the edge of the board to be offset in Y direction.



**8.7** In the interface “Parameter”, the current status of the machine is displayed in the red box.

## Problems that the Bridge Saw Machine may encounter in practical cutting

1. The elevation of the cut sheet is not vertical and has gaps.



### Reasons:

- (1) The speed maybe is too fast.
- (2) The saw blade used is not suitable.
- (3) The verticality of the machine head is deviated.
- (4) The working table platform did not drop in position.
- (5) The head did not reach the 0 degree limit.

### Solution:

- (1). Adjust the feed speed to 15 or so, preferably not exceed it, the best effect is 10 (processing speed).
- (2). Make sure the working table platform is lowered into position and the machine head reaches the limit of 0°.
- (3). The machine head is used for metering to ensure 90 degrees, verticality detection and fine adjustment.
- (4). Confirm that the machine head reaches the limit of 0 degrees, and there is no gap between the machine head and the hard limit.

The newly purchased saw blade should be polished several times with refractory bricks to remove the spikes.